



OWNER'S MANUAL

Osprey Professional Vest/Harness

#745, Vest Only

#745-M, Vest Only w/MOLLE System

#745-MH, Vest w/MOLLE System & Tether

WARNINGS & CAUTIONS

The condition and serviceability of the #745 series Vests shall be evaluated prior to each use by the wearer. This is to include an inspection of the fabric, narrow fabrics (webbing), and stitching for tears, fraying, and loose or broken threads. Hardware and zippers must also be checked for damage or deformation. If inspection reveals any defect the vest shall be removed from service immediately and returned to the factory or other qualified individual for repair or serviceability determination.

The extraction handle on the rear of the vest (#745-MH) is intended as a grab/tow handle for emergency use by rescue personnel only. Extraction handle is not to be used for lifting or hoisting of the wearer. Do not use the extraction handle if back injury to the wearer is suspected.

Do not allow the vest to become excessively soiled. Rinse the vest after exposure to salt or chlorinated water with fresh tap water and allow to completely air dry, away from direct exposure to sunlight.

Special Caution: Vest with Integrated Lifting Harness

The integrated lifting harness of the #745-MH is not to be used as a fall arrest or safety harness. The harness is intended for emergency extraction of aircrew and is not designed as a regular duty harness for deployment and recovery of personnel to the surface.

For duty deployment and recovery, a type specific helicopter hoistable harness such as LSC's #487 TRI-SAR should be used.

Keep leg straps (all versions) stowed in the side pockets when not in use to prevent snag hazard.

Special Caution: Vest with Tether

The tether of the #745-MH is to be used with an appropriate lanyard or restraint system. Lanyard/restraint must be secured to an approved location within the aircraft cabin. When using the tether ensure the waist strap and leg straps are properly donned and adjusted accordingly. Adjust lanyard to minimize slack at all times. **Do not lift by the tether.**

DESCRIPTION

The Osprey Vest/harness is intended to be used by military, tactical, and professional aircrew personnel. The vest is designed as a gear carrier assembly for LSC's Osprey Low Profile Flotation Collar (#740 or #742) and provides stowage pockets for signaling and survival equipment. Primary features of the #745 Osprey Vest are:

- Adjustable size with stow able leg straps for secure fit.
- Synthetic and non-corrosive material/hardware construction.
- Mini-buckle fittings for flotation collar attachment.
- Survival equipment pockets.
- Holster for the SEA egress device.

The #745-M and #745-MH are MOLLE versions which allow for custom pocket layout using compatible, commercially available MOLLE pockets and holsters. MOLLE equipment pockets are sold separately. The #745-MH features an integrated lifting harness for emergency extraction and an integrated rear tether for mobile crewmember restraint within the aircraft.

USING THE #745 SERIES OSPREY VEST

The Osprey Vest shall be donned in standard vest fashion. To secure the vest, close the front zipper and snap the front buckle. The waist straps are to be pulled tight to provide secure and comfortable fit for the wearer. Excess strap lengths shall be folded and stowed to prevent snag hazard. Stow able leg straps are provided to provide a secure fit and ensure optimal flotation characteristics when utilized with Osprey Flotation Collars. Keep leg straps stowed when not in use.

If the vest is issued to, and worn by a single individual the adjustment straps may be trimmed to remove excess length. It is recommended that the wearer allow sufficient adjustment range for seasonal clothing. If trimmed the cut end of the straps shall be seared to prevent fraying, tri-folded, and the tri-fold tacked by qualified personnel.

The #745 Osprey Vest includes mini-buckle attachment fittings to secure LSC's Low Profile Flotation Collar (#740 or #742). Refer to the Flotation Collar owner's manual for instructions to attach the collar to the vest. Remove the flotation collar from the vest when performing inspection and maintenance to the flotation collar.

Special Instructions: Vest with Integrated Lifting Harness

The #745-MH vest has an integrated lifting harness. The leg straps should be stowed when not in use to prevent snag hazard. Before hoisting, remove leg straps from stowage pockets, lace straps around each leg and secure the buckles. Adjust leg straps for a comfortable fit.

To hoist, remove the two hoisting V-rings from the stowage loops on the front of the vest. Attach both V-rings to the hoist hook. Hoist orientation will be seated and slightly reclined. Maintain visual contact with the hoist operator for visual signals/communications.

Special Instructions: Vest with Tether

The #745-MH vest has an integrated tether on the backside of the vest. Tether should be stowed in the hook & loop closure tab when not in use. Prior to using the tether ensure the vest and leg straps are properly donned, all buckles secured, and the waist/leg straps pulled tight for comfortable fit. Tether should be attached to an appropriate lanyard or restraint device so as to secure mobile crewmembers within the aircraft cabin. Adjust lanyard length to minimize slack at all times. Do not lift by the tether.

INSPECTIONS

While LSC has designed and manufactured the vest to meet or exceed industry standards, periodic inspection is necessary to ensure functional reliability. The frequency of the inspection should be determined by the frequency and condition of use. However, the inspection shall not exceed six (6) months.

VISUAL INSPECTION

Thoroughly inspect the mesh, fabric, webbing, and stitching for damage such as cuts, tears, frayed webbing, and broken or loose threads. All hardware including the zipper, mini-buckle fittings, buckles, v-rings and adjusters should be checked for proper function and inspected for damage, deformation or sharp edges. Repair or replace the vest assembly as required. Repairs are to be performed by the factory or qualified personnel only. Vest deemed unserviceable shall be destroyed.

SERVICE LIFE

Ten (10) years from date of manufacture.

WARRANTY

LSC products are warranted to the first consumer purchaser to be free from defects in material or workmanship for a period of twelve (12) months. Please contact LSC for our complete Warranty information and Policies, or visit our website.

LIFESAVING SYSTEMS CORP.

220 ELSBERRY RD.
APOLLO BEACH, FL 33572
PHONE: 813/645-2748
FAX: 813/645-2768

www.lifesavingsystems.com