



OWNER'S MANUAL BOAT SAFETY BELT

#218

WARNING

Belt must be worn above the hips and adjusted for a tight fit for best protection. Insure that the Super Talon Hooks, when attached to the Boat attachment fittings, are locked to prevent a ring roll out when twisting occurs. Failure of the Latch Gate to be engaged in Hook Slot will reduce breaking strength to approximately 1500 lbs. and will prevent Lock Button from engaging lock.

DONNING

1. Belt must be worn around the waist and above the hips.
2. Adjust waist belt for a tight, snug fit.
3. Attach the tethers to secure fittings and verify Super Talon Hooks are locked.
4. Adjust tethers to remove slack.

USER INSPECTION

Before each use inspect all webbing and hardware for damage, wear, corrosion, and proper functioning. Verify proper function of the auto-locking features of Super Talon Hooks as follows: Press and hold Lock Button and check for proper operation of Latch Gate. Latch Gate should be free to move into the open position and return to the closed and locked position when both are released. Verify that the Latch Gate is completely closed and fully engaged in Hook Slot and Lock Button is in locked position.

MAINTENANCE INSPECTION

After exposure to salt water or salt spray, clean belt with fresh water and mild soap. Lubricate the Quick Release Buckle and the tether's Super Talon Safety Hooks periodically with a light lubricant such as WD-40.

SIZES

#218-S Fits waist sizes 27 - 36. Contains Black hang-up strap. #218 Fits waist sizes 34 - 52. Contains Red hang-up strap.

WARRANTY

LSC products are warranted to the first consumer purchaser to be free from defects in material or workmanship for a period of twelve (12) months. Please contact LSC for our complete Warranty information and Policies, or visit our website.

LIFESAVING SYSTEMS CORP.

220 ELSBERRY RD.
APOLLO BEACH, FL 33572
PHONE: 813/645-2748
FAX: 813/645-2768
www.lifesavingsystems.com

Lifesaving Systems Corp.

#F-750-218 OM (Rev A) Updated 2011-10-10



OWNER'S MANUAL BOAT SAFETY BELT

#218

WARNING

Belt must be worn above the hips and adjusted for a tight fit for best protection. Insure that the Super Talon Hooks, when attached to the Boat attachment fittings, are locked to prevent a ring roll out when twisting occurs. Failure of the Latch Gate to be engaged in Hook Slot will reduce breaking strength to approximately 1500 lbs. and will prevent Lock Button from engaging lock.

DONNING

1. Belt must be worn around the waist and above the hips.
2. Adjust waist belt for a tight, snug fit.
3. Attach the tethers to secure fittings and verify Super Talon Hooks are locked.
4. Adjust tethers to remove slack.

USER INSPECTION

Before each use inspect all webbing and hardware for damage, wear, corrosion, and proper functioning. Verify proper function of the auto-locking features of Super Talon Hooks as follows: Press and hold Lock Button and check for proper operation of Latch Gate. Latch Gate should be free to move into the open position and return to the closed and locked position when both are released. Verify that the Latch Gate is completely closed and fully engaged in Hook Slot and Lock Button is in locked position.

MAINTENANCE INSPECTION

After exposure to salt water or salt spray, clean belt with fresh water and mild soap. Lubricate the Quick Release Buckle and the tether's Super Talon Safety Hooks periodically with a light lubricant such as WD-40.

SIZES

#218-S Fits waist sizes 27 - 36. Contains Black hang-up strap. #218 Fits waist sizes 34 - 52. Contains Red hang-up strap.

WARRANTY

LSC products are warranted to the first consumer purchaser to be free from defects in material or workmanship for a period of twelve (12) months. Please contact LSC for our complete Warranty information and Policies, or visit our website.

LIFESAVING SYSTEMS CORP.

220 ELSBERRY RD.
APOLLO BEACH, FL 33572
PHONE: 813/645-2748
FAX: 813/645-2768
www.lifesavingsystems.com

Lifesaving Systems Corp.

#F-750-218 OM (Rev A) Updated 2011-10-10