

P/N 880-RA HOW TO FILL YOUR E-AIR BREATHING DEVICE

⚠ CAUTION:

- a. Do not stand directly over device while filling cylinder. Allow only properly trained technician to fill E-Air cylinder.
 - b. Filling cylinder to fast can cause damage.
 - c. Scuba tank needs to be secured to prevent fall over while filling cylinder, be mindful of your surroundings.
 - d. If air is releasing from the adapter while filling cylinder, close tank valve, wait for air to stop and retighten knurled ring.
- 1) Unscrew fill port dust cover from top of with 3/16 allen wrench. If new remove cap from sealed bag on hose and set aside for final step for step 10. (see figure 1)
 - 2) Clean surrounding area of any debris. Screw refill adapter into fill port at top (see figure 2) of E-Air by turning the knurled ring on adapter to the right (clockwise) until finger tight. (see Figure 2)
 - 3) Clean surrounding area of any debris.
 - 4) Carefully shake regulators to remove any trapped water.
 - 5) Attach adapter to scuba tank valve.
 - 6) FILLING: Fill slowly to prevent heat buildup in the cylinder 40-60 seconds. Allow cylinder to cool to assure a full fill.
 - 7) During filling, press the purge valve to check for proper operation.
 - 8) Close scuba tank valve.
 - 9) Relieve Pressure: Turn knurled ring to left (counter clockwise) while holding collar below knurled ring to relieve pressure in the adapter.
 - 10) Replace fill port dust cover using 3/16 allen wrench finger tight.



Figure 1



Figure 2



**Lifesavings System Corp.
813-645-2748**